

Travler Elevation Calibration

1. Press and hold [POWER] for two seconds or until "Power On" is displayed.
2. Now that the power is on, release the [POWER] button.
3. Press and hold the [ENTER] button for two seconds. The Travler interface will ask if you wish to enter the User Menu. Press [Select] to choose "YES" and then, press [ENTER].
4. The User Menu consist of four choices: Search Mode, Diagnostics, Installation, and Exit. Press [SELECT] until the asterisk is next to "Installation" and then press [ENTER].
5. The interface box will ask for a password. Press [ENTER] four times to enter code "0000" on the display.
6. Press [Enter] to choose "INSTALLATION".
7. From the installation menu, press [SELECT] to move the asterisk to "CALIBRATE EL" then press [ENTER].
8. Press [SELECT] to move the asterisk to "YES"
9. Press [ENTER] to start the elevation calibration procedure. The LCD should now display "CALIBRATE EL In Progress"
10. After a few moments, the Travler interface will display "ON EL HARD STOP? YES *NO". Look at the position of the antenna and is tilted all of the way back as far as it can go and is against the hard stop.
11. Press [SELECT] to move the asterisk to "YES"
12. Press [ENTER], and the LCD will display "CALIBRATE EL SUCCESS". Press and hold [POWER] for two seconds to stow the antenna.